



PAUL N GARDNER COMPANY
9104 GUILFORD ROAD, SUITE H
COLUMBIA, MD 21046 USA

EMAIL GARDCO@ALTANA.COM
PHONE +1-954-946-9454



INSTRUCTIONS

GARDCO DISTRIBUTED PRODUCTS



GERSON® Elite™ Strainer & Dispenser System

Instructions for Mounting, Loading and Dispensing

MOUNTING OF DISPENSER

1. Dispenser can be mounted using key holes on back or with the provided double-sided mounting tape.
2. If attaching with the double-sided mounting tape, mount dispenser on clean surface (isopropyl alcohol is an ideal cleaner), remove release liner, being careful not to touch the surface of the exposed adhesive, and press the dispenser firmly in place. Wait 24 hours before first use.
3. Do not reposition tape once dispenser is pressed in place. If you need to re-position, use a high-quality body side molding tape, such as Norton Part # 636425-05622.
4. Bond becomes permanent after 24 hours; removal requires use of flat implement, such as putty knife, to break foam.

LOADING OF ELITE™ STRAINERS

1. Open the top lid.
2. Open hinged door and the clear revolving door.
3. Take Pod of Elite Strainers for loading into open dispenser. There should be loose material below the tip of the strainer.
4. Pod must be loaded with dispensing tabs facing front. The pod is marked indicating front position.
5. Make sure end tabs are generally aligned and gently place pod into dispenser.
6. Once the pod is resting on the dispenser ring, reach into the bottom of the dispenser to guide the tip of the pod into the centering V groove.
7. Close the hinged door. Leave the lid open.
8. The pod is completely perforated to allow removal.
9. With one hand, hold the pod of strainers above the perforation line and grasp the loose material at the bottom with your other hand.
10. Firmly but slowly pull down on the bottom part of the pod. The bottom section will separate and may be removed.
11. Remove the top portion and remainder of the pod through the top of the dispenser. CAUTION: Removing strainers from protective pod before loading into dispenser may cause contamination of the filter mesh from body oils or particulates!
12. Close the top lid.
13. Dispense strainers one at a time using the Dispensing Tab.
14. Be sure to close clear revolving door when dispenser is not in use. This keeps strainer mesh free of ambient dust and particulates.



ELITE PAINT STRAINER SYSTEM

COMPLETE CONTAMINATION CONTROL

A revolutionary total system, providing a clean-room manufactured strainer, dust-free storage and “no touch” tab dispensing to ensure that each strainer is 100% contamination-free at final use. Developed to provide the critical increased level of purity required for preparing today’s waterborne, basecoat and clear-coat paints and endorsed by the leading manufactures of refinish paints.

Clean-Room Produced

Manufactured using Gerson’s exclusive fully automated clean-room manufacturing process and spectrographically lot-tested filter material to ensure that each strainer is pure and 100% contamination-free

Protected Storage and Dispensing

Automatically packaged in sealed pods to protect their contaminant-free purity until final use, and dispensed from the patent-pending Elite strainer dispenser.



Eliminate the Risk of Finish Re-do

Paint Strainers made by hand contain significant levels of environmental and processing contaminants such as ambient shop-floor dust, hand oils and particulates from process steps, creating an unacceptable contamination risk to expensive paint finishes.

Gerson Elite Dispenser Starter Kit - (each kit contains 2 pods of 125 strainers (250)

Call for Pricing

ST-902903	1 dispenser & 2-190 micron strainer pods
ST-902905	1 dispenser & 2-150 micron strainer pods
ST-902907	1 dispenser & 2-226 micron strainer pods
ST-902909	1 dispenser & 2-125 micron strainer pods

Replacement Strainers (Note: Quantity price breaks available - Call for quotation)

ST-902210	226 microns, orange mesh, case of 500 (medium).....
ST-902410	190 microns, yellow mesh, case of 500 (fine)
ST-902610	150 microns, green mesh, case of 500 (extra fine)
ST-902810	125 microns, blue mesh, case of 500 (extra fine)
ST-9031	Wire type strainer stand